

How to connect a scale to Produmex PDC

Produmex Manufacturing is a legacy product and Boyum IT Solutions no longer sells new installations for it.

This customization example shows how to use a scale in Produmex PDC with the help of the Produmex WMS ScaleComm Service.

We will add a new Weigh button to the screens where the products can be received and materials can be issued. When this button is pressed, a user query fills the product/material Quantity field with the measured weight. The used scale will be identified based on the work center.

Prerequisites:

- Installed Produmex Manufacturing and Produmex PDC
- Installed Produmex WMS up to version 7.0
- Installed Produmex ScaleCommService

For more information about Produmex PDC customization please see: [Customization Technology](#).

1. Add Weigh button to PDC screens

Open the Customization Fields table via: Tools > User Defined Windows > BXPCUSTFD - Customization Fields. For more information about the Customization Fields user table please see: [Create custom field](#)

Add the Weigh button to the following screens:

- Stop Job/Partial Job
- Product (for by-products)
- Product batch
- Material
- Material batch

| Field Name | Field Type | Label | Screen | Visible | Protected |
|------------|------------|-------|------------------------------------|---------|-----------|
| PWeigh | Button | Weigh | StopJobScreen | Yes | No |
| BPWeigh | Button | Weigh | ProductsAdvScreen | Yes | No |
| MWeigh | Button | Weigh | MaterialsAdvScreen | Yes | No |
| PBWeigh | Button | Weigh | ProductBatchNumbersAdvScreen | Yes | No |
| MBWeigh | Button | Weigh | MaterialBatchNumberPickerAdvScreen | Yes | No |

In order to use the UoM conversion for batch managed items, add the following user fields on the Customization Fields table as well.

| Field Name | Field Type | Screen | Visible | Protected | ReadOnly |
|------------|------------|--------------------|---------|-----------|----------|
| ItemM | String | MaterialsAdvScreen | No | Yes | Yes |
| ItemP | String | ProductsAdvScreen | No | Yes | Yes |

3.2. Configure ScaleComm Service

Open the configuration file of the ScaleComm Service from its installation folder. Define the scales with the ScalesCodes. Add the code of the scales from the Organizational Structure. To define multiple scales, separate them by comma. Make sure that the 'Skip Polling' option is set to false and adjust the Polling Interval if needed. For more information about the ScaleComm Service configurations please see: [Application configurations](#).

3.3. Assign work centers to the scales

Open the [Scale weigh result user table](#) via the following path: Tools > Default forms > PMX_SCWR – Scale weigh result.

- Add the scale code to the Code field.
- Add the work center code to the user field you created for work centers.
- Add the UoM of the scale to the user field you created for UoM for PDC.

When the ScaleComm Service runs, it will add the weight to the 'Weigh' field of the matching scale.

In order to convert between units of measurements correctly, make sure that both the UoM of the item and the UoM of the scale is defined properly on the following standard SBO tables:

- Weight - Setup (OWGT)
- Units of Measure - Setup (OUOM)

Please note: When using SAP HANA, value names are case sensitive.

3.4. PDC Settings

Make sure that the '*PDC Custom Validation UQ setting enabled*' option is enabled on the [Thin Client tab](#) of Produmex Manufacturing Settings.

4. Add the custom queries

Add the custom queries with the Query Manager. For more information about PDC custom queries please see: [Create a SAP user query](#).

4.1. Product

Query name: *BXPPSMobilePDC_StopJobScreen_PWeigh_click*

```
SELECT
'TextQuantity' as Click$,
(
SELECT [@PMX_SCWR].U_PMX_WEIGH * OWGT.WightInMG / OWGT2.WightInMG
FROM [@PMX_SCWR]
JOIN OWGT ON OWGT."UnitDisply" = [@PMX_SCWR].U_UOMPDC
JOIN OITM ON OITM."ItemCode" = [CurrentPDCBooking.ProductCode]
JOIN OWGT AS OWGT2 ON OWGT2."UnitDisply" = OITM."InvntryUom"
WHERE U_WORKCENTER= [CurrentPDCBooking.WorkCenterCode]
)
AS TextQuantity,
'TextRejectedQuantity' as Click$
```

Query name: *BXPPSMobilePDC_StopJobScreen_PWeigh_click_after*

```
SELECT 'TextRejectedQuantity ' as Click$
```

4.2. By-product

Query name: *BXPPSMobilePDC_ProductsAdvScreen_BPWeigh_click*

```
SELECT
'TextQuantity' as Click$,
(
SELECT [@PMX_SCWR].U_PMX_WEIGH * OWGT.WightInMG / OWGT2.WightInMG
FROM [@PMX_SCWR]
JOIN OWGT ON OWGT."UnitDisply" = [@PMX_SCWR].U_UOMPDC
JOIN OITM ON OITM."ItemCode" = [SelectedProduct.ProductCode]
JOIN OWGT AS OWGT2 ON OWGT2."UnitDisply" = OITM."InvntryUom"
WHERE U_WORKCENTER= [CurrentPDCBooking.WorkCenterCode]
)
AS TextQuantity
```

This query runs when the user clicks on the 'Weigh' button.

First it clicks in the Quantity field.

Then it selects the weigh from the PMX_SCWR table based on the current work center and it converts the measured weigh from the UoM of the scale defined on the UoM for PDC field to the UoM of the item specified on the Produmex Inventory tab of the Item Master Data.

Query name: *BXPPSMobilePDC_ProductsAdvScreen_BPWeigh_click_after*

```
SELECT 'TextProduct' as Click$
```

This query runs after the click on the 'Weigh' button. It clicks in the Product field in order to validate the quantity added with the previous query.

4.3. Product and by-product batch

Query name: *BXPPSMobilePDC_ProductsAdvScreen_ButtonSerialBatch_click*

```
SELECT ${SelectedProduct.ProductCode} AS 'ItemP'
```

This query fills the ItemP user field with the item code of the selected product when the Serial/Batch button is pressed. As the ItemP user field is a 'Protected' field, the field value can be used in custom queries for events of the next screen.

Query name: *BXPPSMobilePDC_ProductBatchNumbersAdvScreen_PBWeigh_click*

```
SELECT
'TextBatchQuantity' as Click$,
(
SELECT [@PMX_SCWR].U_PMX_WEIGH * OWGT.WightInMG / OWGT2.WightInMG
FROM [@PMX_SCWR]
JOIN OWGT ON OWGT."UnitDisply" = [@PMX_SCWR].U_UOMPDC
JOIN OITM ON OITM."ItemCode" = ${ItemP}
JOIN OWGT AS OWGT2 ON OWGT2."UnitDisply" = OITM."InvntryUom"
WHERE U_WORKCENTER= ${CurrentPDCBooking.WorkCenterCode}
)
AS TextBatchQuantity,
'TextBatch' as Click$
```

Query name: *BXPPSMobilePDC_ProductBatchNumbersAdvScreen_PBWeigh_click_after*

```
SELECT 'TextBatch' as Click$
```

4.4. Material

Query name: *BXPPSMobilePDC_MaterialsAdvScreen_MWeigh_click*

```
SELECT
'TextQuantity' as Click$,
(
SELECT [@PMX_SCWR].U_PMX_WEIGH * OWGT.WightInMG / OWGT2.WightInMG
FROM [@PMX_SCWR]
JOIN OWGT ON OWGT."UnitDisply" = [@PMX_SCWR].U_UOMPDC
JOIN OITM ON OITM."ItemCode" = ${SelectedMaterial.ItemCode}
JOIN OWGT AS OWGT2 ON OWGT2."UnitDisply" = OITM."InvntryUom"
WHERE U_WORKCENTER= ${CurrentPDCBooking.WorkCenterCode}
)
AS TextQuantity,
'TextItem' as Click$
```

Query name: *BXPPSMobilePDC_MaterialsAdvScreen_MWeigh_click_after*

```
SELECT 'TextItem' as Click$
```

4.5. Material batch

Query name: *BXPPSMobilePDC_MaterialsAdvScreen_ButtonSerialBatch_click*

```
SELECT $[SelectedMaterial.ItemCode] AS 'ItemM'
```

Query name: *BXPPSMobilePDC_MaterialBatchNumberPickerAdvScreen_MBWeigh_click*

```
SELECT  
'TextBatchQuantity' as Click$,  
(  
SELECT [@PMX_SCWR].U_PMX_WEIGH * OWGT.WightInMG / OWGT2.WightInMG  
FROM [@PMX_SCWR]  
JOIN OWGT ON OWGT."UnitDisply" = [@PMX_SCWR].U_UOMPDC  
JOIN OITM ON OITM."ItemCode" = $[ItemM]  
JOIN OWGT AS OWGT2 ON OWGT2."UnitDisply" = OITM."InvntryUom"  
WHERE U_WORKCENTER= $[CurrentPDCBooking.WorkCenterCode]  
)  
AS TextBatchQuantity
```

Query name: *BXPPSMobilePDC_MaterialBatchNumberPickerAdvScreen_MBWeigh_click_after*

```
SELECT 'TextBatch' as Click$
```


5. Customized production data collection process

Process the PDC booking as described in [Production Data Collection](#).

5.1. Stop Job/Partial Job screen

After pressing the Stop or the Partial button, the user is prompted to the Stop Job/[Partial Job screen](#). An additional Weigh button is displayed on the screen. Press this button to weigh the produced quantity instead of adding it manually for the main product.

If the main product is managed by batches and multiple batches were produced in this job, weigh every batch on this screen.




5.2. Products screen

On the [Products screen](#) the main product and by-products can be received.

To add the produced quantity for the by-product by weighing, select the by-product and press the Weigh button. If the by-product is managed by batches and multiple batches were produced in this job, weigh every batch on this screen.

Please note: It is not possible to modify the produced quantity for the main product on this screen.



| # | Code | Name | Weigh | Uom | Work center | Uom for PDC |
|---|---------|------|-------|-----|-------------|-------------|
| 1 | scale01 | | 425 | | wWC | g |
| 2 | scale02 | | 0.412 | | wAS | kg |
| 3 | scale03 | | 0.379 | | wCT | kg |
| 4 | | | | | | |

OK Cancel

5.3. Product, by-product batch

If the (by)-product is managed by batches, select the (by)-product and press the Serial/Batch button in order to add the batch numbers. On the [Product Batch screen](#) scan the batch number then press the Weigh button to add the quantity by weighing.

Please note: The combined quantity of the batches must be equal to the (by)-product quantity specified on the previous screen.

Mobile PDC

TEST_WMSMF (PMX_BUDTOSH2) - John Doe

Server: 17.00.10004.10020
Client: 17.00.10004

10/12/17 03:24 PM

Product Batch Numbers

Production Order #136 pMP1101 (Main product) UoM g

Operation 136-1 (OPP1 - Operation)

Item pBP011 (By-product (batch)) SSCC

Batch Number Batch Number

Quantity 204 [Best Before]

| Batch Number | SSCC | Quantity | [Total Quantity] | Batch Number | [Best Before] |
|--------------|------|----------|------------------|--------------|----------------------|
| BP171010 | | 208 | 208 | | 1/1/0001 12:00:00 AM |
| BP171011 | | 204 | 204 | | 1/1/0001 12:00:00 AM |

Quantity 412 g Of 412 g


Rejected Quantity 0 g Of 0 g

Done
Cancel
Rejected
Weigh
Delete

5.4. Material

On the [Materials screen](#) materials to be consumed can be reported.

Select the material and press the Weigh button in order to add the quantity by weighing. If the material is managed by batches and multiple batches are going to be consumed in this job, weigh every batch on this screen.



5.5. Material batch

If the material is managed by batches, select the material and press the Serial/Batch button in order to add the batch numbers. On the [Material Batch screen](#) scan the batch number then press the Weigh button in order to add the quantity by weighing.

Please note: The combined quantity of the batches must be equal to the material quantity specified on the previous screen.

Last update: 2021/04/20 09:24 implementation:manufacturing:pdconnect_scale https://wiki.produmex.name/doku.php?id=implementation:manufacturing:pdconnect_scale

Mobile PDC TEST_WMSMF (PMX_BUDTOSH2) - John Doe 10/12/17 03:42 PM

Material Batch Number Picker

Production Order #136 pMP1101 (Main product) UoM g

Operation 136-1 (OPP1 - Operation)

Item mM3475 (Material)

Batch Number Bin Location

Quantity 2,000

| [Batch] | Bin Location | Quantity | [Avail BL Qty] | [Avail WH Qty] | [Total Qty] |
|----------------|--------------|----------|----------------|----------------|-------------|
| MM171010 02 | | 230 | 2,500 | 2,500 | 230 |
| MM171011 02 | | 2,000 | 2,500 | 2,500 | 2,000 |

Quantity 2,230 g Of 2,230 g

Done Cancel Weigh Delete

From: <https://wiki.produmex.name/> - **Produmex**

Permanent link: https://wiki.produmex.name/doku.php?id=implementation:manufacturing:pdconnect_scale

Last update: 2021/04/20 09:24

